



Southern Cross Game Reserve PTY (Ltd) PO Box 156 Augrabies 8874

Tel no: + (27)54 453 0001

Email: info@tutwalodge.co.za

Website: www.tutwalodge.co.za

Southern Cross Game Reserve Airstrip Procedure and Flight Rules

Upon receiving this request to land, the Southern Cross Central Booking office will process the request and in the event permission to land is forthcoming, will provide, in writing prior to landing, a **CONSENT TO LAND REFERENCE NUMBER**. No aircraft are allowed to land at Southern Cross Game Reserve landing strips or helipads without consent from Southern Cross and without a signed Disclaimer/Waiver.

The minimum height to be maintained over Southern Cross Game Reserve is **1500ft** above ground level (AGL). This height should be maintained until the joining procedure and final approach to a landing strip or helipad. Aircraft should maintain height until close to the landing site or landing strip and then descent as per the required safety operating instructions of the aircraft. For departures, aircraft should ascent to the recommended height as soon as possible after take-off, as close to the take-off site as possible, before leveling off and entering a cruise.

- **Power lines are on the threshold of runway 09. Take extreme caution when approaching to land on 09 or when taking off runway 27 or a go around on 27.**

All aircraft must following standard procedures for approaches and departures from the airstrips or helipads.

Pilots are requested to broadcast their intentions 5 minutes before landing on frequency **124.80 MHZ**

General information:

Length:	1.2 Km
Width:	22 Meters
Surface:	Compacted gravel
Direction:	09 - 27
Elevation:	674 Meters
Co-ordinates:	S28°35.761' E019°50.525'